

ERA

806

Universal Pressbolt Fitting Instructions

Installing a Universal Pressbolt

To fit a Universal Pressbolt you will require the following tools:

- Bradawl (or drill with 2.5mm drill bit)
- 3mm drill bit (if fitting to metal windows)
- 13mm drill bit (if fitting to recessed wooden doors (B))
- Posidriv screwdriver
- Pencil

If fitting to metal windows, drill 3mm pilot holes.

If fitting to hardwood, drill 2.5mm pilot holes.

- A** Close door or window and select position of pressbolt. Position lock mechanism 1mm away from edge of door or window. Mark position of screw holes and screw lock mechanism to door or window (add packing plate if required).
- B Recessed Doors** - Use packing plate to ensure there is a minimum of 6mm of timber between steel bolt and edge of frame. Push bolt upwards to mark hole position. Drill a 13mm hole in door frame and fit plastic ferrule into hole.
- C Flush Doors** - Position receiver plate on door frame to enable steel bolt on pass through. Mark position of screw holes and screw into position (recess receiver plate if necessary).
- D Metal Windows** - Ensure lock mechanism is in locked position (steel bolt showing). Position lock mechanism so that steel bolt touches window handle. Unlock using key and adjust position of lock mechanism until handle can be rotated past lock without touching.

Additional Information

Maintenance - Use moist cloth only to clean all types of finish, household abrasives and solvents may affect the surface finish.

Operation - Push bolt to lock. Turn key anti-clockwise to unlock.

Useful Tips - Pressbolts can be fitted either vertically or horizontally at top/bottom of doors or windows.

